

System Technology > System Technology of CPU and Overall System > Firmware Update > Updating the Firmware of AC500 Devices from the SD Card > Update via FTP > Update Steps:

## Update Steps:

1. To update your CPU via FTP, you first must configure and activate the FTP server with the set checkbox "Allow Firmware update".  
=> (details see in documentation of ABB Control Builder Plus Software, chapter *Configuration of the FTP server*).
2. Connect to your CPU's system ramdisk (i.e. memory location "ramdisk").  
=> (details see in documentation of ABB Control Builder Plus Software, chapter *Connection to a PLC Running a FTP Server*).
3. Switch your CPU to STOP.
4. Copy the according .gza file to the system ramdisk (= memory location *ramdisk*):

Product	Name of Firmware File
PM55x-ETH, PM56x-ETH	Pm55xE.gza
PM57x-ETH, PM58x-ETH	Pm58xN.gza
PM59x, PM59x-ETH	Pm59xRD.gza
PM595-x-4ETH	Pm595.gza

⇒ The CPU will automatically update its firmware with the downloaded file, flashing the RUN and ERR LEDs.

As of V2.5 copy file *SDCARD.INI* to the system ramdisk. As of V2.5 all firmware updates are triggered by the command file *SDCARD.INI*. This is independent from the way of the firmware update (SD card, FTP, *write file to plc, ...*). In addition a result file of the firmware update is generated (*SDCARD.RDY*, identical path as *SDCARD.INI*). The evaluation of this file shows the results of the updates.

5. Wait until all LEDs ceased toggling.
6. Power cycle your PLC and the new firmware will be loaded.

### Potential problems:

- If you cannot connect to your CPU, check if the FTP server is configured and running correctly.
- If you cannot download the file, increase your configured "Sessions". Some FTP clients require more than one FTP connection for their operations, because logins and downloads are handled in separate sessions.
- If you downloaded the .gza file into the ramdisk, but the CPU does not start to update (i.e. the LEDs do not toggle):
  - Check, if the option *Allow firmware update* is set for the FTP server.
  - Check, if the CPU is in STOP state; in RUN state no firmware update is allowed.
  - Check, if you copied the correct firmware file.
  - Check, if you copied the file into the correct memory location (correct is *ramdisk* - incorrect is "sramdisk", "userdisk", "flashdisk", "sdcard").